



"SHOWBIZ SET AND COSTUME INSTRUCTIONS"

Christmas 88



SHOWBIZ CENTER STAGE




RED TINSEL
GARLAND
(BOTH TREES)

GREEN/SILVER
GARLAND W/
LIGHTS

BILLY BOB'S STAGE



ROLFE'S STAGE



RED TINSEL
GARLAND

GREEN/SILVER
GARLAND W/LIGHTS

SHOWBIZ PIZZA CHRISTMAS DECOR PACKAGE
1987

SUPPLIES INCLUDED IN KIT:

- 1 ROLL OF DACRON SNOW
- 1 LB. IRIDESCENT GLITTER
- 1 BOX OF STYROFOAM SNOW
- 4 BOXES OF TWINKLE LIGHTS
- 2 DOZEN POINTSETTAS
- 1 ROLL NYLON SUSPENSION THREAD
- 2 DOZEN 6" SNOWFLAKES
- 2 DOZEN 4" SNOWFLAKES
- 1 48" WREATH, BOW AND APPLES
- 10 PKGS. GREEN/SILVER GARLAND
- 6 PKGS. RED GARLAND
- 1 DOZEN SANTA HATS
- 4 RED AND WHITE SCARVES
- 1 PAIR RED BEACH BEAR SHORTS
- 1 RED AND WHITE STRIPED EARL NIGHTSHIRT
- 1 SHOWTAPE
- 1 BACKGROUND TAPE

GENERAL SUPPLIES REQUIRED:

- STAPLE GUN, STAPLES
- LADDER AND STEP STOOL
- SCISSORS
- T-PINS
- TIE-WRAPS
- LARGE SAFETY PINS
- ROPE OR HEAVY NYLON CORD

YOU ARE NOW READY TO BEGIN THE
CHRISTMAS INSTALLATION.

COSTUMES:

1. SANTA HATS HAVE BEEN PROVIDED FOR THE FOLLOWING CHARACTERS:

EARLE - SQUEEZE ON OVER CAP AND SAFETY PIN TO FUR HAIR IN
2 PLACES.

ROLFE - PLACE OVER ONE EAR; SAFETY PIN TO FUR 2 TIMES.

SUN - PLACE OVER ONE RAY AND STAPLE TO WOOD FRAME ON BACK.

DOOK - PULL ON OVER HAT; SAFETY PIN TO FUR 2 TIMES.

CHOO CHOO BEAR - SAFETY PIN TO FUR

FATZ - SAFETY PIN TO FUR

BEACH BEAR - SAFETY PIN TO FUR

MITZI - SAFETY PIN TO FUR, PLACED COMPLETELY OVER ONE EAR.

MOON - PULL OVER HEAD AND STAPLE TO WOOD FRAME.

LAMP POST- SET ON TOP OF LAMP

BILLY BOB - SAFETY PIN TO FUR IN 2 PLACES.

LOONEY BIRD - PULL ON OVER HIS LEAFY ANTENNA AND SAFETY PIN
TO HEAD.


CHRISTMAS LIGHTING FOR ROCK A FIRE EXPLOSION SHOW

EACH SET OF CHRISTMAS LIGHTS (1 SET PER STAGE) WILL BE ENERGIZED BY A SEPERATE CIRCUIT. UNPLUG THE APPLAUSE SIGN ON STAGE RIGHT (ROLFE & EARL). PLUG THE CHRISTMAS LIGHTS INTO THE APPLAUSE SIGN OUTLET. UNPLUG BOTH OF DOOK'S DRUM LIGHTS AND PLUG CHRISTMAS LIGHTS INTO THE DRUM LIGHTS SOCKET. ON STAGE LEFT (BILLY BOB) THE CHRISTMAS LIGHTS WILL BE PLUGGED INTO THE OUTLET PREVIOUSLY USED FOR THE FIRE/STILL.

SOME SHOWS ARE INSTALLED WITH THE APPLAUSE, DRUM, AND FIRE LIGHTS HARD-WIRED TO AN ELECTRICAL TRACK. IN THESE CASES YOU MAY USE AN ADAPTER TO CONVERT THE INCANDESCENT SOCKET TO A STANDARD 110 VOLT SOCKET, OR A 110 VOLT SOCKET MAY NEED TO BE WIRED IN. IF YOU HAVE A HARD-WIRED SYSTEM AND HAVE QUESTIONS PERTAINING TO THE WIRING. PLEASE CALL THE TECHNICAL SERVICES DEPT.

GREEN AND SILVER TINSEL:

1. OUTLINE ALL 3 STAGES: STAPLE GARLAND IN A STRAIGHT LINE ALONG TOP EDGE OF VALANCE, DROP DOWN ALONG BOTH SIDE DRAPES, AND STAPLE IN A STRAIGHT LINE DIRECTLY BENEATH MOLDING AT EDGE OF STAGE FLOOR.
2. INTERTWINE ONE SET OF TWINKLE LIGHTS WITH ONE PACKAGE OF GARLAND FOR EACH STAGE; TIE-WRAP EVERY FEW FEET. LAY THE GARLAND ON THE FLOOR OF EACH STAGE, CREATING A "PUDDLE" EFFECT AROUND THE CHARACTERS. (CENTER STAGE WILL REQUIRE A LITTLE MORE THAN ONE PACKAGE OF GARLAND). FOLLOW THE LIGHTING INSTRUCTIONS PROVIDED FOR WIRING AND HOOKING UP. THESE TWINKLE LIGHTS WILL BE PROGRAMMED. (ONE SET IS PROVIDED AS A SPARE).



SNOW:

1. TEAR OFF BIG HUNKS OF SNOW AND BLANKET THE FOLLOWING :
(USING A STAPLE GUN IF NECESSARY).
DOOKS STUMP
CHOO-CHOO'S STUMP
TOP OF FATZ'S ORGAN
HANGING OFF THE TIP OF BEACH BEAR'S
SURFBOARD (HOT GLUE)
LOONEY BIRD'S BARREL RIM
NECK OF GAS PUMP (HOT GLUE)
TOP OF KETTLES - ROLFE'S STAGE
TOP OF BASE DRUM
FLAT BLACK SECTIONS OF TREES ON BILLY BOB'S STAGE
IN THE BOUGH OF THE WREATH
2. USE THE REST OF THE SNOW TO FILL IN THE "PUDDLES" ON ALL 3 STAGES CREATED BY THE GREEN AND SILVER GARLAND. FLUFF IT UP TO LOOK REAL, USE THE CLUMPS OF FLOWERS TO COVER OVER AS BASES FOR MOUNDS AND DRIFTS (NO FLOWERS SHOULD REMAIN EXPOSED) THE BARE BOULDERS, BILLY BOB'S JUG, AND FROG CAN BE REPLACED ON TOP OF THE SNOW - WITH MORE SNOW ON TOP OF THEM! PULL SOME SNOW UP OVER THE FLOWERS PAINTED ON THE TREES ON BILLY BOB'S STAGE AND STAPLE. USE CLUMPS OF FLOWERS IN FRONT OF THE LIGHTS OF HIS STAGE AND COVER WITH SNOW.

GLITTER:

SPRINKLE THE IRIDESCENT GLITTER WHEREVER IT SNOWED! USE ONE HALF OF THE GLITTER AND SAVE THE REST FOR NEXT YEAR.

STYRO SNOW: - USE ONLY HALF THE BOX; SAVE THE REST FOR NEXT YEAR.

SCATTER THE LOOSE SNOW MAINLY OVER TOP OF THE CLUSTERS ON THE FLOOR, AND EXTEND IT OUT BEYOND THE TINSEL ONTO THE GRASS OR ASTROTURF ON THE FLOOR OF THE STAGE, SO IT LOOKS NATURAL. DO NOT GET TOO CLOSE TO THE FRONT EDGES OF THE STAGE OR THE MOVING CURTAINS WILL WHISK IT AWAY.

PLACE THE REMAINING POINTSETTAS INTO THE SNOW FOR COLOR.

NOW START DRINKING HOT CHOCOLATE AND SINGING CHRISTMAS CAROLS

Y O U ' R E F I N I S H E D !!!

SHOWBIZ SET AND COSTUME INSTRUCTIONS - CHRISTMAS 88

Date of Origin: 1988

Archived: 1-14-26

Submission by "The Great Historian"

Version 1.0

The documents contained herein are for educational use only.
Please do not replicate, redistribute, or make any unauthorized
printings. All intellectual property including characters,
artwork, photography, and slogans are trademark and/or
copyright their respective owners.

